

PPPoE Plus Configuration

XXXX Communication Technology Co., Ltd

Tel: (86)

Fax: (86)

URL:

Email:

All rights reserved. Printed in the People's Republic of China.

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise without the prior written consent of XXXX Communication Technology Co., Ltd.

XXXX makes no representations or warranties with respect to this document contents and specifically disclaims any implied warranties of merchantability or fitness for any specific purpose. Further, XXXX reserves the right to revise this document and to make changes from time to time in its content without being obligated to notify any person of such revisions or changes.

XXXX values and appreciates comments you may have concerning our products or this document. Please address comments to:

XXXX Communication Technology Co., Ltd

Tel: (86)

Fax: (86)

URL:

Email:

All other products or services mentioned herein may be registered trademarks, trademarks, or service marks of their respective manufacturers, companies, or organizations.

Contents

- Chapter 1 PPPoE Plus Configuration 1**
 - 1.1 Introduction to PPPoE 1
 - 1.1.1 PPPoE packet..... 1
 - 1.1.2 PPPoE Plus..... 1
 - 1.2 PPPoE Plus Configuration 2
 - 1.2.1 Enabling PPPoE Plus 2
 - 1.2.2 Option Content Configuration 2
 - 1.2.3 PPPoE Plus Monitor and Maintenance 2

Chapter 1 PPPoE Plus Configuration

1.1 Introduction to PPPoE

The Point-to-Point Protocol over Ethernet (PPPoE) is a network protocol for encapsulating Point-to-Point Protocol (PPP) frames inside Ethernet frames. It is used mainly with DSL services where individual users connect to the DSL modem over Ethernet and in plain Metro Ethernet networks. It was developed by UUNET, Redback Networks and RouterWare and is available as an informational RFC 2516.

1.1.1 PPPoE packet

PPPoE protocol packet is as following:




Figure 1-1 PPPoE packet

1.1.2 PPPoE Plus

PPPoE+ is short for PPPoE Intermediate agent which is proposed early in DSL FORM to define according to user line mark proportion of RFC 3046. The realization theory is similar to DHCP Option82 which makes some complement on PPPoE protocol packet. After accessing device get PPPoE protocol packet, insert user physical information for uplink direction, and strip it for downlink direction before transmission.

This function should work with PPPoE Plus server.

MyPower switch supports two kinds of PPPoE Plus packet:

- Standard mode: it contains user info: connected port, VLAN, MAC of local switch.

"0 0/0/0:4096.VID Switch MAC/0/0/slot/subslot/port"

- HuaWei mode: it can communicate with HuaWei BRAS. It contains user info: Connected port, VLAN, hostname and MAC of local switch.

"0 0/0/0:4096.VID Switch MAC/hostname/0/slot/sub-slot/port"

1.2 PPPoE Plus Configuration

1.2.1 Enabling PPPoE Plus

PPPoE packet will be forwarded to trust port. Trust port should be configured after enable this function. Generally, PPPoE plus will add option content to PPPoE packet. If the received PPPoE packet has contained option content, the handling strategy will be defined.

Table 1-1 Enabling PPPoE Plus

Operation	Command	Remarks
Enter global configuration mode	configure terminal	-
Enter interface configuration mode	interface ethernet device/slot/port	-
Enabling PPPoE Plus	pppoeplus	Required
Configuring trust port	pppoeplus trust	Required
Configure option strategy	pppoeplus strategy { drop keep replace }	Optional

1.2.2 Option Content Configuration

The option content need to be added before PPPoE packet forwarding out, the contents of this option can be determined by a variety of ways. Option content can be specified in interface configuration mode. If the content is not specified, it will be constructed according to configured rules. If pppoe plus type is self-defined, the format should also be specified.

Table 1-2 Option content configuration

Operation	Command	Remarks
Enter global configuration mode	configure terminal	-
Configure PPPoE Plus packet format	pppoeplus type { huawei standard self-defined { circuit-id { <string> vlan port switch-mac hostname client-mac }* remote-id { <string> switch-mac hostname client-mac }* }	Optional
Configure format	pppoeplus format { binary ascii }	Optional
Configure delimiter	pppoeplus delimiter { colon dot slash space }	Optional
Enter interface configuration mode	interface ethernet device/slot/port	-
Specify circuit ID	pppoeplus circuit-id string	Optional

1.2.3 PPPoE Plus Monitor and Maintenance

After finishing above configuration, user can check the configurations by command below.

Table 1-3 PPPoE Plus monitor and maintenance

Operation	Command	Remarks
Display PPPoE Plus configuration	show pppoeplus [interface-list]	On any configuration

PPPoE Plus Configuration

		mode
--	--	------