

EFM Configuration

XXXX Communication Technology Co., Ltd

Tel: (86)

Fax: (86)

URL:

Email:

All rights reserved. Printed in the People's Republic of China.

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise without the prior written consent of XXXX Communication Technology Co., Ltd.

XXXX makes no representations or warranties with respect to this document contents and specifically disclaims any implied warranties of merchantability or fitness for any specific purpose. Further, XXXX reserves the right to revise this document and to make changes from time to time in its content without being obligated to notify any person of such revisions or changes.

XXXX values and appreciates comments you may have concerning our products or this document. Please address comments to:

XXXX Communication Technology Co., Ltd

Tel: (86)

Fax: (86)

URL:

Email:

All other products or services mentioned herein may be registered trademarks, trademarks, or service marks of their respective manufacturers, companies, or organizations.

Contents

| | |
|---|----------|
| Chapter 1 EFM Configuration | 4 |
| 1.1 Brief Introduction to EFM..... | 4 |
| 1.1.1 EFM Main Function | 4 |
| 1.1.2 EFM Protocol Packets | 5 |
| 1.2 Configuration EFM | 5 |
| 1.2.1 EFM Configuration Task List | 5 |
| 1.2.2 EFM Basic Configuration | 6 |
| 1.2.3 EFM Timer Parameter Configuration | 6 |
| 1.2.4 Configuring Remote Failure Indication..... | 7 |
| 1.2.5 Configuring Link Monitoring Capabilities | 8 |
| 1.2.6 Enabling Remote Loopback..... | 9 |
| 1.2.7 Rejecting Remote Loopback Requests Initiated by Remote..... | 9 |
| 1.2.8 Initiating a Remote Loopback Request..... | 9 |
| 1.2.9 Starting Remote Access Function MIB Variable | 10 |
| 1.2.10 MIB Variable Access Requests Initiated by Remote | 10 |
| 1.2.11 Display and Maintenance of EFM..... | 11 |

Chapter 1 EFM Configuration

1.1 Brief Introduction to EFM

EFM (Ethernet of First Mile) as the first mile Ethernet, defined by the IEEE 802.3ah standard, used for the two devices point to point Ethernet link between the management and maintenance.

1.1.1 EFM Main Function

EFM Ethernet can effectively improve the management and maintenance capabilities to ensure the stable operation of the network, its main features include:

Table 1-1 EFM main function

| Function | Remarks |
|------------------------------|--|
| EFM auto-discovery | EFM functionality built on the basis of connections, EFM connection establishment process is achieved by the auto-discovery of EFM. EFM work in two modes: active mode and passive mode, EFM connected only by the active mode of EFM entity initiated the passive mode EFM physical entity can only wait for the end of the connection requests are in a passive mode of the two an EFM can't be established between the entities connected. |
| Remote failure indication | When the device detects a link event of an emergency, the fault will end EFM entity's Flag by Information OAMPDU fault information field (the type of emergency event link) EFM notification to the peer entity. In this way, administrators can log information by observing the dynamic understanding of the link state, the corresponding error in a timely manner for processing. Event types, including emergency Link Fault, Dying Gasp and Critical Event of three. |
| Link monitoring capabilities | Link monitoring function is used in a variety of environments and found that the link layer fault detection, EFM through interactive Event Notification OAMPDU to monitor the link: When the end of the EFM to detect the general physical link event, the Event Notification sent to its peer OAMPDU for notification, the administrator can log information by observing the network to dynamically control the situation. Event types include general link-errored-symbol-period, errored-frame, errored-frame-period, errored-frame-seconds four. |
| Remote loopback | Remote loopback is active mode EFM entity sends to the remote except OAMPDU than all other messages, the remote receives the packet forwarding address is not its purpose, but the road back to its original The end. Remote loopback is controlled by remote Loopback Control OAMPDU remote loopback or remote loopback operation to cancel the function can be used to detect the link quality and positioning of link failure. |

| | |
|--|---|
| Remote access to MIB variable function | EFM entities can interact with Variable Request / Response OAMPDU far end of the entity to obtain the MIB variable value. Include Ethernet MIB variable chain on the road all the performance parameters and error statistics. It provides a local EFM physical entity on the far side of the general performance and error detection mechanisms. |
|--|---|

Description:

We said so to the EFM port functions as "EFM Entities.

1.1.2 EFM Protocol Packets

EFM working in the data link layer, the protocol packet is called OAMPDU (OAM Protocol Data Units, OAM protocol data unit). EFM is through regular interaction between the device OAMPDU to report link status, enabling network administrators to effectively manage the network.

Table 1-2 EFM protocol packets

| Message type | Effect |
|------------------------------------|--|
| Information OAMPDU | EFM entity status for the information (including local information, the remote information and custom information) sent to the remote entity EFM, EFM connections to maintain. |
| Event Notification OAMPDU | Generally used for link monitoring on local and remote connected EFM physical link failures in the warning. |
| Loopback Control OAMPDU | Mainly use for remote loopback control in order to control the EFM loopback state of remote device. The packet has the information of enabling or disabling loopback .Enabling or disabling remote loopback based on this information. |
| Variable Request / Response OAMPDU | Mainly used for remote MIB variable values, in order to achieve the end of the remote state prosecution. |

1.2 Configuration EFM

1.2.1 EFM Configuration Task List

Table 1-3 EFM configuration task list

| Configuration Tasks | | Remark | Detailed configuration |
|-------------------------------------|--|----------|------------------------|
| EFM basic configuration | Start EFM | Required | 1.2.2 |
| | EFM mode configuration | Optional | 1.2.2 |
| EFM timer parameter configuration | Configure the interval to send handshake packets EFM | Optional | 1.2.3 |
| | Configure the connection timeout EFM | Optional | 1.2.3 |
| | Response timeout configuration | Optional | 1.2.3 |
| Configure remote failure indication | | Optional | 1.2.4 |
| Configure link | Start link monitoring capabilities | Optional | 1.2.5 |

| | | | |
|---|--|----------|--------|
| monitoring capabilities | Configure errored-symbol-period event detection parameters | Optional | 1.2.5 |
| | Configure errored-frame event detection parameters | Optional | 1.2.5 |
| | Configure errored-frame-period event detection parameters | Optional | 1.2.5 |
| | Configure errored-frame-seconds event detection parameters | Optional | 1.2.5 |
| Configuration far end loopback function | Start remote loopback | Optional | 1.2.6 |
| | Reject remote loopback requests initiated by remote | Optional | 1.2.7 |
| | Initiate a remote loopback request | Optional | 1.2.8 |
| Configure remote access function MIB variable | Start the remote access function MIB variable | Optional | 1.2.9 |
| | MIB variable access requests initiated by remote | Optional | 1.2.10 |
| Display and maintenance of EFM | | Optional | 1.2.11 |

1.2.2 EFM Basic Configuration

EFM mode of operation is divided into proactive mode and passive mode, when the EFM function enabled, the Ethernet port started to use the default mode of operation and the establishment of its peer port connected EFM.

Table 1-4 EFM basic configuration

| Operation | Command | Remarks |
|---------------------------------|--|---|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Start EFM | efm | Required By default, EFM is off |
| EFM mode configuration | efm mode {passive active} | Optional By default, EFM mode to active mode |

1.2.3 EFM Timer Parameter Configuration

EFM connection is established, both ends of the EFM entity will be a certain time interval to send Information OAMPDU cycle to detect whether the connection is normal, the interval is called the interval to send handshake packets. If one end of

the connection timeout EFM entity within an entity does not receive remote EFM sent Information OAMPDU, EFM is considered disconnected.

EFM handshake by adjusting packet transmission interval and the connection timeout, the connection can change the EFM detection accuracy. With configuring OAMPDU remote request message to the response timeout, then discard the message which receiving the later response message to the OAMPDU if the time is out.

Table 1-5 EFM timer parameter configuration

| Operation | Command | Remarks |
|--|--|-------------------------------------|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Configure the interval to send handshake packets EFM | efm pdu-timeout <i>time</i> | Optional The default value is 1s |
| Configure the connection timeout EFM | efm link-timeout <i>time</i> | Optional The default value is 5s |
| Response timeout configuration | efm remote-response-timeout <i>time</i> | Optional The default value is 2s |

Caution:

Because EFM connection times out, the local entity will EFM EFM aging and physical connection to the end of the relationship, the EFM connection is broken, so the connection must be greater than the timeout interval to send handshake packets (Recommended for 3 times or more) , otherwise it will lead to EFM connection instability.

1.2.4 Configuring Remote Failure Indication

Table 1-6 Configure remote failure indication

| Operation | Command | Remarks |
|---------------------------------|--|--------------------------------|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Start remote failure indication | efm remote-failure {link-fault dying-gasp critical-event} | Optional By default, remote |

| | | |
|--|--|-------------------------------|
| | | failure indication is enabled |
|--|--|-------------------------------|

Description:

Remote failure indication function device supports a single-pass function required to detect the local emergency link to the remote event notification, in the single-pass functions are not supported on the device, the local emergency is detected only in the event link end of reporting alarms and can't notify the remote.

1.2.5 Configuring Link Monitoring Capabilities

Table 1-7 Configure link monitoring capabilities

| Operation | Command | Remarks |
|---|--|--|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Start link monitoring capabilities | efm link-monitor {errored-symbol-period errored-frame errored-frame-period errored-frame-seconds} | Optional By default, the link monitoring is enabled |
| Configure errored-symbol-period event detection cycle | efm link-monitor errored-symbol-period window high win-value1 low win-value2 | Optional |
| Configure errored-symbol-period event detection threshold | efm link-monitor errored-symbol-period threshold high th-value1 low th-value2 | Optional |
| Configure errored-frame event detection cycle | efm link-monitor errored-frame window win-value | Optional |
| Configure errored-frame event detection threshold | efm link-monitor errored-frame threshold th-value | Optional |
| Configure errored-frame-period event detection cycle | efm link-monitor errored-frame-period window win-value | Optional |
| Configure errored-frame-period event detection threshold | efm link-monitor errored-frame-period threshold th-value | Optional |
| Configure errored-frame-seconds event detection cycle | efm link-monitor errored-frame-seconds window win-value | Optional |
| Configure errored-frame-seconds event detection threshold | efm link-monitor errored-frame-seconds threshold th-value | Optional |

Description:

- errored-symbol-period threshold event detection cycle and a 64-bit integer value, **high** and **low** parameter values, respectively, after the value of the high and low 32-bit, that is, the integer value = **(high * (2 ^ 32)) + low**.

1.2.6 Enabling Remote Loopback

By default, loopback at the far end is in the off state. It can only support the far end loopback device starts far end loopback.

Table 1-8 Start remote loopback

| Operation | Command | Remarks |
|---------------------------------|--|----------|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Start remote loopback | efm remote-loopback | Optional |

1.2.7 Rejecting Remote Loopback Requests Initiated by Remote

As the remote loopback function will be affected normal business in order to avoid this situation, users can configure the local port of the peer sent from the Loopback Control OAMPDU control, which refused to end the remote initiated EFM loopback request.

Table 1-9 Reject remote loopback requests initiated by remote

| Operation | Command | Remarks |
|---|--|--|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Reject remote loopback requests initiated by remote | efm remote-loopback {ignore process} | Optional By default, the remote refused to initiate a remote loopback request |

1.2.8 Initiating a Remote Loopback Request

Table 1-10 Initiate a remote loopback request

| Operation | Command | Remarks |
|----------------------------|---------------------------|---------|
| Enter global configuration | configure terminal | - |

| | | |
|------------------------------------|--|----------|
| mode | | |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Initiate a remote loopback request | efm remote-loopback {start stop} | Optional |

Description:

- Only when the port EFM connection has been created, and the mode of EFM proactive mode, in order to launch on the far side of the port loopback request.
- Only the port side and far side far side loopback support feature, and in full-duplex chain on the road to achieve the far end loopback.
- In the open far end loopback, it will cause all data traffic in off; when the exit far end loopback, the local and remote port will be back to normal. Lead to far-side exit port loopback reasons: use no EFM command to close the EFM function, use the EFM remote-loopback stop command or exit the far end loopback connected EFM over time and so on.

1.2.9 Starting Remote Access Function MIB Variable

Table 1-11 Start the remote access function MIB variable

| Operation | Command | Remarks |
|---|--|--|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Start the remote access function MIB variable | efm variable-retrieval | Optional By default, remote access to MIB variable is enabled |

1.2.10 MIB Variable Access Requests Initiated by Remote

Table 1-12 MIB variable access requests initiated by remote

| Operation | Command | Remarks |
|---|--|----------|
| Enter global configuration mode | configure terminal | - |
| Enter port configuration mode. | interface ethernet device / slot / port | - |
| Port for the remote device MIB variable value | show efm port port-id-list remote-mib {phyadminstate autonegadminstate} | Optional |
| Access to remote devices | show efm remote-mib {fecability fecmode} | Optional |

| | | |
|----------------------------|--|--|
| global MIB variable values | | |
|----------------------------|--|--|

Description:

- Only when the port EFM connection has been created, EFM working model is for the proactive mode, the far side far side port supports MIB variable access function to the port on the far end of the MIB variable for initiating the request.
- Currently only supports remote query capability of FEC, FEC mode, port status and port to enable auto-negotiation enabled, the other MIB variables can later be added on demand to achieve.

1.2.11 Display and Maintenance of EFM

After completing the above configuration, you can use the following command to display the EFM configuration.

Table 1-13 Display and maintenance of EFM

| Operation | Command | Remarks |
|--------------------------------------|---|--------------------------------|
| Show EFM protocol running | show efm status <i>interface [interface-name]</i> | Perform either of the commands |
| Display summary information EFM | show efm summary | |
| Display EFM find information | show efm discovery <i>interface [interface-name]</i> | |
| Show EFM protocol packet statistics | show efm statistics <i>interface [interface-name]</i> | |
| Clear EFM protocol packet statistics | clear efm statistics <i>interface [interface-name]</i> | |